

WILD HORSES **FOUR WHEEL DRIVE**

640 North El Dorado Street Stockton, CA 95202 Phone (209)943-0991 Fax (209)943-7923

www.wildhorses4x4.com

Locker Blocker

#8742 Date 6/7/03 rev. 0

Parts

Locker Blocker

Hardware

10 ea. 5/16 bolts

Thanks for purchasing the Locker Blocker from Wild Horses Inc. Please allow us to take a moment to point out some of the features of the Locker Blocker that make it a cut above the others on the market.

1. We use a 3/8" thick precision lazer cut full differential ring. This adds total support for the front differential cover.
2. The four support bars give the main hoop unmatched strength for this style of diff guard. It also just looks better than some of the three bar offerings.
3. The bend of the main bar will give you a some extra protection for your tie rod in the event of a head on with a big forward momentum stopping rock.

Instructions:

If you need a new diff gasket now would be the time to change it. Please note we have made every attempt to make these Locker Blockers nothing more than a bolt on install however we have still run into a few fit issues on some covers. This seems to stem from different stamping dies used for the covers. In the worsts case scenario you will need to file or grind a small amount of material off the back of the ring. Follow these instructions and your install will be perfect.

1. Remove all ten bolts from the diff cover.
2. Change gasket if desired. Clean gasket mounting surfaces and remove any burs or nicks. Make your mounting surface flat. Do not put sealer on the gasket at this time.
3. Test fit the Locker Blocker to the differential cover. You want a completely flat install. Start all ten bolts and then tighten them down evenly. If the Blocker will not sit flat you will need to file or grind a small amount off the inside back of the ring. File until the ring sits flat on the diff cover.
4. Once you have obtained a nice flat fit you can apply sealer to the gasket and bolt the cover and Locker Blocker onto the differential housing. Tighten the bolts down evenly to the factory spec of 15-25 ft lbs.

Clear Gearz notes: You will not need the Clear Gearz retaining ring if you are installing a Locker Blocker with the Clear gearz. Tighten bolts to 10 ft lbs. per the Clear Gear instructions.

